



Step One

Insert your receiver into your tow bar as you would normally and insert the hitch pin.

Leave a mark where the hitch and tow bar meet.



Step Two

Remove your receiver from your tow bar and align one shim against the receiver. Ensure that cross section between the tab and body aligns with this mark.

On the tail of the shim, mark where your receiver ends.



Step Three

Bend the tail at the marked point. You will want to use a straight edge (such as a bench) to assist in a clean bend.

Trim away any surplus material. Repeat until all shims are cut.



Step Four

Adding one shim at a time, insert your receiver and shim into your tow bar until you are satisfied.

Watch the Video Tutorial via QR Code

Scan the QR Code on the right to watch our YouTube video on installing the Couplemate™ Anti-Rattle Hitch Shim Kit.

For more information, feel free to reach out to our friendly sales team.

